

URGENT SAFETY NOTICE

Do not operate the below gas range cookers with the grill door closed.

When the grill is operating the grill door must always be in the open position. If the grill is operated with the grill door closed, the air supply to the grill burner is restricted causing dangerous levels of <u>Carbon</u> <u>Monoxide</u> to be produced.

Product SKU	Product Name	Colour
44445410	BEL C/RANGE 100G	Charcoal
44445411	BEL C/RANGE 100G	Silver
44440221	BEL C/RANGE 100GT	Charcoal
44440222	BEL C/RANGE 100GT	Silver
44442980	BEL C/RANGE 100GT	Black
44442981	BEL C/RANGE 100GT	Cream
44442982	BEL C/RANGE 100GT	Jalapeno
44440979	BEL C/CLASSIC 100G LPG	Silver

Safety Inspection:

If you own any of the aforementioned Cookers please contact us to arrange for one of our engineers to carry out a free safety inspection and complete any modifications required.

Call 0800 093 9945 with your product code and serial number. The lines are open 9-5pm Monday – Friday.

The serial number can be found on the data plate at the front edge of the appliance and on the rear of the appliance.

Appliance Use:

All gas appliances must be installed and operated in accordance with the manufacturer's instructions supplied with the cooker. Correct use and adequate ventilation is essential to ensure safe use of these cookers. Using an appliance for any purpose, other than that for which it is designed, can cause serious safety issues.

The grill cavity in these appliances are design for open door grilling and the grill must not be used as an oven, a space heater or for any other purpose.